

Descaler

Geraete Entkalker

Description

Concentrate! Against scale building in electrical appliances (preserves the taste). Ideal for espresso and pad coffee machines.

Action

Highly effective and economical concentrate. Does not develop toxic fumes and is odour-free. With regular application, the taste quality will be preserved, the life-cycle of the appliances extended and, in addition, energy is saved. Removes professionally and easily lime crusts and deposits on equipment used at home and in the industry.

Scope of application

Coffee machines, fully automatic coffee machines, automatic espresso and pad machines, water heaters, steam irons, immersion heaters, washing machines.

Also for fittings, shower heads and water strainers.

Application

Coffee machine / Water heaters:

Fill 1/4 cup of Equipment Descaler together with 2 cups of water into the machine. Switch on and let one cup pass through. Switch appliance off and leave it for 10 minutes. Switch the machine on again and let the rest pass through. Afterwards, rinse 2-3 times with fresh water

Washing machine:

250 ml (1/4 bottle) into the water of one washing machine fill. Heat to 40 °C and leave to soak for one hour. Then switch on the main wash cycle and let the machine run through incl. rinsing process.

Fittings, shower heads, water strainers:

Apply the Equipment Descaler using a cloth or sponge, leave to soak and rinse with water. Small parts can also be inserted into a solution diluted 1:1 with water for a short period of time. Repeat process if necessary.

Please note

Be sure to observe the equipment manufacturer's descaling instructions. Acidic product. Caution with splatters on surfaces sensitive to acids such as marble, enamel, chrome, fabrics and the like.

Technical data

- Density: 1.04 g/ml
- pH value: 1.5-2.0
- Appearance: clear liquid
- Odour: neutral

Safety notes

- Irritant
- Irritating to eyes, respiratory system and skin.
- Keep out of the reach of children.
- Avoid contact with skin and eyes. In case of contact with eyes, rinse immediately with plenty of water and seek medical advice.
- Wear suitable gloves.
- If swallowed, seek medical advice immediately and show this container or label.

Info Telephone: +49 (0) 55 41 / 70 03 - 491

Packaging unit

1000 ml bottle (4 pcs. in carton)

Order no. 390 368

There is a huge diversity of application conditions and areas of applications of our products. Therefore, we can only give general instructions for use in the product information concerned. They can and shall only give general advice. Check and adapt the use of the products to local conditions and the surfaces to be treated. Always pre-test the products on an inconspicuous area in all cases of doubt or in absence of experience. We would be happy to offer you advice if you have special requirements.

We shall only be liable for incomplete or incorrect technical data in case of gross default on our part (wilful misconduct or gross negligence).