

# Furniture Cleaner and Care – High Gloss

### Properties:

- Gently cleans
- Maintains shine
- For high-gloss, lacquered and film-coated surfaces

### Area of application

For high-gloss, lacquered, film-coated and other sensitive furniture surfaces in the home, such as e.g. high-gloss fronts in kitchens, living areas, bathrooms and WCs. High-gloss fronts are extremely sensitive and must be cleaned with particular care. Removes streaks, smears, fingerprints and stains and ensures a streak-free shine. Reduces re-soiling and prevents premature signs of ageing.

### Application:

Simply spray evenly onto the surface to be treated and wipe off with a damp cotton cloth. If necessary, rub glossy surfaces dry with a soft cloth.

### Technical data:

Raw material base:	Water, non-ionic surfactants, anionic surfactants and fragrances 1 g/cm <sup>3</sup>
Density:	8 – 9
pH value:	Clear,
Colour:	pleasant
Odour:	

### Storage:

Store containers tightly closed in a cool place, but not exposed to frost. Keep out of reach of children.

### Notes:

Microfibre cloths often leave fine abrasion marks on high-gloss surfaces, which can cause the surface to become dull. Therefore, always use a damp cotton cloth, a soft cloth or a chamois leather for cleaning.

Please refer to the safety data sheet for safety-related information.

### Item number EAN

048402074

### Pack

4044899484745

750 ml



### Note:

All information and data in this information sheet correspond to our practical experience and laboratory tests and are based on the current state of technology. However, they can only provide general information and do not constitute a guarantee of properties. As the conditions under which storage, transport and processing take place are beyond our control, no legal liability can be derived from this information. It is the responsibility of the user to check the products for their suitability for the intended use under the respective conditions.